

Clean-Up Polluted Waterways with

BENEFICIAL MUD BALLS

- 8 parts soil
 - 2 parts fermented bran
- Then add
- 1 qt of Activated EM™ per 16 qts material

- Add water if not enough liquid to form mud ball.
- Let mud balls air-dry & ferment for 2 wks before using.
- Target at least 1 mud ball per square yard
at the bottom of the polluted water (lake, pond, bay, etc)

